

Uitvoering	B cm	D cm	H cm	S1	S2
1,5 AL+1,5+RH+1,5+RP				3.435	3.604
1,5	145	105	76	845	887
1,5 L/R	120	105	76	715	751
1,5 ZA	95	105	76	586	614
11/4	130	105	76	779	817
11/4 L/R	105	105	76	647	680
11/4 ZA	80	105	76	520	544
1	115	105	76	647	680
1 L/R	90	105	76	520	544
1 ZA	65	105	76	456	478
RH (RECHTE HOEK)	105	105	76	795	832
RHXL (RECHTE HOEK XL)	122	122	76	1.039	1.089
RP (RONDE POEF)	105	105	45	524	548



B = breedte, D = diepte, H = hoogte, in cm. Uitvoeringscodes volgens fabrikant: L/R = arm links of rechts, ZA = zonder arm, LCH = longchair, H = hoekelement.

Stoffen en leder per groep

S1: BELLA, MISCANTO, SEMPRE, TORO, TRENZA

S2: ADORE, BE GENTLE, BE LOVELY, BERGEN, BRAVE, CAYENNE, COCO, ENTER, FUSION, JEEP, LEAF, LODGE, MACAN, MIAMI, MITO, RIVER, SHEEP, SILENT, VENGA

Technische gegevens

GERAAMTE	hardhouten regels + vezelplaat
ZITTING	nosag veren + hr sg35
RUG	elastische single band + polyether sg 35
BEKLEDING	stof
POTEN	hout, zwart, koloniaal, onbewerkt
STIKSEL	ton sur ton